



PS500




Quick Operation Guide




Switch On






Manual Datalog



Switch Off






Pump



Backlight On

Max

Min



Reset


Manual Zero





Alarm Indicators





Gas Alarm Acknowledge




Self Test




Flow Fault



Zero Fault



Calibration Overdue



Battery Life



Charging

