

PS200 Series

Auto Bump & Calibration

1



Open



2



Insert


3



Close/testing



4



5



Pass



Fail

6



Open/remove

